

PEUGEOT 308 DOGBARRIER

Part no: 40370



ASSEMBLY INSTRUCTIONS:

- Lower the backrest for the backseat, this makes the assembly go smoother.
- Remove any cargocover.
- Press the plugs in place onto the open pipeends of the barrier
- Place the barrier in the car as shown in the picture.
- Latch the hooks in the seat back brace and put the threaded end through the sockets of the barrier.
- Fastened with the wheelnuts.

MOUNTING HARDWARE:

- Wheelnut M8 2st.
- Threaded Hook nr:22 2st.
- Plug IKP16 2st.

