

**ASSEMBLY INSTRUCTIONS:**

- Slide the bolts out and latch the barrier into the mounting holes of the car.
- Latch the hooks in the seat back brace and put the threaded end through the sockets of the barrier.
- Fastened with the knobs.

**MOUNTING HARDWARE:**

- Sliding bolt M10 x 130 2
- Spring 2
- Ball M10 2
- Hook nr:44b 2
- Knobs M8 2

