

**ASSEMBLY INSTRUCTIONS:**

- Press the plugs in place onto the open pipeends of the barrier
- Lower the backrest of the backseat
- Place the barrier against the C-bars of the car.
- Put the washers in the holes in the sidepanels.
- Thread the straps through the loops on the barrier.
- Put the hooks on the straps.
- Latch the hooks into the holes in the washers.
- Tighten the straps.

**MOUNTING HARDWARE:**

- |                    |   |
|--------------------|---|
| ● Straps L.70      | 2 |
| ● Hook 10042-28J11 | 2 |
| ● Washer 20 x 86   | 2 |
| ● Outer plug UKB16 | 2 |

